



Aura Gallery Setup Instructions

Download the Aura Gallery Software

Go to www.fishman.com/support/aura/blender/ and download the Aura Gallery software for the Imaging Blender. Run the installer and follow the prompts and instructions.

MIDI Requirements

The Aura Gallery transfers new Sound Images from your computer to the Aura Pedal through a MIDI device. Your computer must have a MIDI capable device for this to happen. Connect the appropriate MIDI device (see below) to your computer and connect the 5-pin **MIDI Out** plug to the **MIDI In** jack on the rear panel of the Aura pedal. If the cable has a second MIDI In plug, it is unused.

MIDI Cables

You'll need to purchase a MIDI interface and cable. These devices are available in most computer and music stores.

If your computer has a USB port, you'll need a USB MIDI interface. This device will have a second MIDI in connector that goes unused.

Download Sound Images

Go to www.fishman.com/support/aura/blender/ and download the complete Image archive for the Imaging Blender. Unzip the file to a secure location on your computer's hard drive. Be sure to choose a location where this folder will not be moved or erased until you uninstall the Aura Gallery software.

Add Sound Images to the Aura Gallery Application

Follow the instructions in the Aura Gallery Help File to add Sound Images to the Library, create a Load List and transfer the Sound Images to the Aura Pedal. Sound Images must be transferred from the unzipped Image archive folder.

For more information regarding Sound Image transfer and software functionality, please refer to the Aura Image Gallery Quick Reference.